




L60
Driving Support ECU Assembly



* 1 : w/ Dynamic Radar Cruise Control
* 2 : w/o Dynamic Radar Cruise Control



L60
Driving Support ECU Assembly



L60
Driving Support
ECU Assembly




32

P

(*1)

2




L103
Fuse Block

1

R

(*1)

(IG)




11

2A

B

(*1)

L48(A)
Windshield Wiper Switch Assembly



2

A

B

(*1)

4

A

W

(*1)

2

B


3

B

L133(B)
Junction
Connector

R

(*1)



* 1 : w/ Dynamic Radar Cruise Control